

# Safety Bulletin



## POST Barricading Standard

As part of the POST rollout in 2010, a “Barricading Standard” was implemented as a mandatory minimum requirement for maintenance work area protection as well as when appropriate on construction sites (see below). This requirement is to help ensure that technicians are protected while working in high traffic areas.

Here is an overview of the specific barricading requirements along with photos showing proper implementation.

### Stop Element

Use your service vehicle

### Visibility–Use cones

Every 6 feet  
28 inches high  
Flagged

### Isolation

Continuous barrier (poles or tape)

### Safety Perimeter

6 feet from workplace  
Speed bumps (optional)



*Contractors use barricading walls and/or fencing for larger projects*